

Apparecchi di misura di precisione. Sensori e Sistemi
per grandezze elettriche, termiche e meccaniche



Operation Manual for Torque Sensors

For Type 86-2554



Apparecchi di misura di precisione. Sensori e Sistemi
per grandezze elettriche, termiche e meccaniche



Imprint

Valid for...	Torque sensor type 86-2554
Reprint Interdiction	Reprints, even in extracts, only with written authority.
Modification	Technical changes reserved.

References in this Text

1.6 Warning Notes; Page 6



Attention must be paid to the accident prevention regulations of the trade associations. Coverings and casings are necessary before operating the sensor. This is also valid for commissioning, maintenance and trouble shooting.

Duties of the coverings and casings are:

- ⇒ Protection from detaching parts
- ⇒ Protection from contusion and shear
- ⇒ Prevention from reaching rotating parts
- ⇒ Prevention from being tangled up and/or getting caught by parts

Coverings may

- ⇒ Not grind
- ⇒ Not rotate

Coverings are also necessary outside of operating and motion travel areas of persons. These demands can be modified if other sufficient safety devices are available. During operation, the safety precautions must be operative. By vibrations, damages can occur at the device.

4.0 Mechanical Assembly; Page 8



Caution: During the assembly inadmissibly large forces may not act on the sensor or the couplings. Connect the sensor electrically during the assembly and observe the signal, the measurement signal may not exceed the limit values



During the assembly, the sensor must be supported to protect it from falling down.



Admissible assembly offset from rotor to stator: see data sheet.

4.3.1 Couplings; Page 11



- The power transmission of the tension ring hubs or the clamping ring hubs occurs frictionally locked; the contact surface between tension ring and hub and between clamping ring and hub are lubricated on-site
- Hub drillings and shaft ends must be totally free of grease during the assembly. Greasy or oily drillings or shafts do not transfer the maximum torque of the coupling.
- The shafts may not be equipped with a keyway.
- Hub and tension or clamping ring must be totally unbent, if necessary loosen the screws.

4.3.2 Alignment of the Measurement Arrangement; Page 11



For further references see coupling manual and data sheet for the torque sensor.

4.3.3 Assembly Example of Hubs with Tension Ring; Page 11



For further references see coupling manual.

4.3.4 Assembly Example of Hubs with Clamping Ring; Page 12



For further references see coupling manual.

4.3.5 Assembly Example of Hubs with Feather Key Hub; Page 12



For further references see coupling manual.

6.1 Engaging; Page 13



Warming-up period of the torque sensor is approx. 5 min.

6.4.2 Natural Resonances; Page 14



An operation of the device in natural resonance can lead to permanent damages.

Contents

1	Read First	5
1.1	Safety and Caution Symbols	5
1.2	Intended Use	5
1.3	Dangers	5
1.3.1	Neglecting of Safety Notes	5
1.3.2	Remaining Dangers	5
1.4	Reconstructions and Modifications	5
1.5	Personnel	5
1.6	Warning Notes	6
2	Term Definitions	6
2.1	Terms	6
2.2	Definition of the Pictograms on the Torque Sensor	6
3	Product Description	6
3.1	Mechanical Setup	7
3.2	Electrical Setup	7
4	Mechanical Assembly	8
4.1	Basic Assembly	9
4.1.1	Example for assembly with Clamping Set	9
4.1.2	Example for Assembly with Radial Clamping Hub	10
4.2	Examples for Torque Sensors without integrated Couplings	10
4.2.1	Use of Centre Bore	10
4.3	Couplings	11
4.3.1	Couplings	11
4.3.2	Alignment of the Measurement Arrangement	11
4.3.3	Assembly Example of Hubs with Tension Ring	11
4.3.4	Assembly Example of Hubs with Clamping Ring	12
4.3.5	Assembly Example of Hubs with Feather Key Hub	12
5	Electrical Connection	12
5.1	Pin Connection	12
5.2	Cable	13
5.3	Shielding Connection	13
5.4	Running of Measuring Cables	13
5.5	Speed Sensor (Option)	13
6	Measuring	13
6.1	Engaging	13
6.2	Direction of Torque	13
6.3	Static / Quasi-Static Torques	13
6.4	Dynamic Torques	14
6.4.1	General	14
6.4.2	Natural Resonances	14
6.5	Speed Limits	14
6.6	Disturbance Variables	14
7	Maintenance	14
7.1	Maintenance Schedule	14
7.2	Rotating Torque Sensors	14
7.3	Trouble Shooting	15
8	Decommission	15
9	Transportation and Storage	15
9.1	Transportation	15
9.2	Storage	16
10	Disposal	16
11	Calibration	16
11.1	Proprietary Calibration	16
11.2	DKD-Calibration	16
11.3	Re-Calibration	16
12	Data Sheet	16

1 Read First

1.1 Safety and Caution Symbols



Caution:

Injury Risk for Persons
Damage of the Device is possible.



Note:

Important points to be considered.

1.2 Intended Use

Torque sensors are intended for the measurement of torques. This measurement is further suitable for control tasks. The valid safety regulations should be absolutely respected. The torque sensors are not safety components in the sense of the intended use. The sensors need to be transported and stored appropriately. The assembly, commissioning and disassembling must take place professionally.

1.3 Dangers

The torque sensor is fail-safe and corresponds to the state of technology.

1.3.1 Neglecting of Safety Notes

At inappropriate use, remaining dangers can emerge (e.g. by untrained personnel). The operation manual must be read and understood by each person entrusted with the assembly, maintenance, repair, operation and disassembly of the torque sensor.

1.3.2 Remaining Dangers

The plant designer, the supplier, as well as the operator must plan, realize and take responsibility for safety-related interests for the sensor. Remaining dangers must be minimized. Remaining dangers of the torque measurement technique must be pointed out.

Human mistakes must be considered. The construction of the plant must be suitable for the avoidance of dangers. A danger-analysis for the plant must be carried out.

1.4 Reconstructions and Modifications

Each modification of the sensors without our written approval excludes liability on our part.

1.5 Personnel

The installation, assembly, commissioning, operation and the disassembly must be carried out by qualified personnel only. The personnel must have the knowledge and make use of the legal regulations and safety instructions.

1.6 Warning Notes



Attention must be paid to the accident prevention regulations of the trade associations. Coverings and casings are necessary before operating the sensor. This is also valid for commissioning, maintenance and trouble shooting.

Duties of the coverings and casings are:

- ⇒ Protection from detaching parts
- ⇒ Protection from contusion and shear
- ⇒ Prevention from reaching rotating parts
- ⇒ Prevention from being tangled up and/or getting caught by parts

Coverings may

- ⇒ Not grind
- ⇒ Not rotate

Coverings are also necessary outside of operating and motion travel areas of persons. These demands can be modified if other sufficient safety devices are available. During operation, the safety precautions must be operative. By vibrations, damages can occur at the device.

2 Term Definitions

2.1 Terms

Measuring Side:

Mechanical connection of the torque sensor in which the torque to be measured is applied. Usually this side has the smallest moment of inertia.

Drive Side:

Mechanical connection of the torque sensor on the opposite side of the measuring side, usually with the largest moment of inertia. At static torque sensors the housing is fastened on this side.

Low Torque Resistance Side:

The shaft of the arrangement (drive, load) which can be turned considerably smaller with torque than the nominal torque of the torque sensor $M \ll M_{nenn}$.

2.2 Definition of the Pictograms on the Torque Sensor

The measuring side of the torque sensor is designated as follows:

Measuring side:  or M

More information can be found on the data sheet, if needed.


3 Product Description

The sensor measures static and dynamic torques. The mounting position of the torque sensor is horizontally.

Caution: it is to be differentiated between measuring side and drive side, see data sheet of the sensor: <http://www.burster.it>

3.1 Mechanical Setup

The sensor consists of a stationary part, the stator and a rotary part, the rotor.



3.2 Electrical Setup

The electronics integrated in the sensor consists of two parts.

The first part is in the stator and has following tasks:

- Stabilization of the supply voltage
- Electric supply of the rotor electronics through the rotating transformer
- Preparation of the measurement signal from the rotor
- Readout of the torque measurement signal to the cable connection

The second part of the electronics is placed in the rotor of the torque sensor and has following functions:

- Supply of the SG full bridge with d.c. voltage
- Preparation of the electrical torque measurement signal
- Transmission of the measurement signal to the stator

4 Mechanical Assembly



Caution: During the assembly inadmissibly large forces may not act on the sensor or the couplings. Connect the sensor electrically during the assembly and observe the signal, the measurement signal may not exceed the limit values




During the assembly, the sensor must be supported to protect it from falling down.




Admissible assembly offset from rotor to stator: see data sheet.


For transportation and easier assembly, the torque sensor is delivered with fixing




plates.



Assembled fixing plates



Removed fixing plates




Without fixing plates

The installation and the alignment of the torque sensor occurs with mounted fixing plates. Afterwards remove the 3 fixing plates and control position of shaft to stator:

- a) Axial alignment of the shaft
- b) Evenness of the air gap (shaft may not grind at the stator)


4.1 Basic Assembly

4.1.1 Example for assembly with Clamping Set



Setup completely assembled.

4.1.2 Example for Assembly with Radial Clamping Hub



4.2 Examples for Torque Sensors without integrated Couplings

By special adapters, the sensor can be connected to any connection element.

Disturbance variables such as

- radial misalignments,
- angular misalignments,
- axial misalignments

always need to be balanced (double-jointed coupling).

4.2.1 Use of Centre Bore

Each part which is led-through the torque sensor means a torque shunt.


- By this, a part of the torque is led-through passed the sensor.
- This proportion is not measured → the shunt must be small compared to the measured torque.

The large centre bore is suitable for the lead-through of

- hydraulic hoses
- pneumatic hoses
- rods

Please note

- The lead-through part may not acquire torque which will influence the measurement result
- The shunt torque for the transposition of the led-through parts must be very small against the applied torque.



At this configuration consider:


$$M_{ges} = M_t + M_s$$

$$M_t \gg M_s \quad \Rightarrow \quad \text{e.g. } M_s < \frac{1}{1000} M_t$$

Otherwise a disturbance of the measuring signal will occur through the torque shunt.

4.3 Couplings

We recommend multi-disc couplings for our torque sensors. Couplings must be able to balance an axial, radial or angular offset of the shafts and not allow large forces to act on the sensor. The assembly instructions of the respective coupling manufacturer must be considered.



axial misalignment/radial misalignment/angular misalignment

4.3.1 Couplings



- The power transmission of the tension ring hubs or the clamping ring hubs occurs frictionally locked; the contact surface between tension ring and hub and between clamping ring and hub are lubricated on-site
- Hub drillings and shaft ends must be totally free of grease during the assembly. Greasy or oily drillings or shafts do not transfer the maximum torque of the coupling.
- The shafts may not be equipped with a keyway.
- Hub and tension or clamping ring must be totally unbent, if necessary loosen the screws.

4.3.2 Alignment of the Measurement Arrangement

Precisely alignment of the couplings reduces the reaction forces and increases the durability of the couplings. Disturbance variables are minimized as well.

Due to the multitude of applications, an alignment of the coupling with a straight edge in two levels, vertical to each other, is sufficient.

However, in drives with high speed an alignment of the coupling (shaft ends) with a dial gauge or a laser is recommended.


Further Points to be considered

- The axis height of the torque sensor (data sheet) must be considered.
- An air gap between rotor and stator must be available. The rotor may not touch the stator in any operating condition.
- Axial position of the rotor to the stator: see data sheet.



For further references see coupling manual and data sheet for torque sensor.

4.3.3 Assembly Example of Hubs with Tension Ring




- Shift the hubs with the proper appliance onto the shafts and position correctly.
- Uniformly tighten the clamping screws with the torque wrench **in sequence and in several circulations** to the torque indicated in table 1.
- Control the applied tightening torque after 5-10 operating hours.



For further references see coupling manual

4.3.4 Assembly Example of Hubs with Clamping Ring


- Shift the hubs with the proper appliance onto the shafts and position correctly.
- Tighten the clamping screw with the torque wrench to the indicated torque.
- Control the applied tightening torque after 5-10 operating hours.



For further references see coupling manual

4.3.5 Assembly Example of Hubs with Feather Key Hub

- Shift the hubs with the proper appliance onto the shafts and fix them axially (see picture below). The axial fixation occurs through a threaded pin (set screw), which radially presses on the feather key, or through a pressure-cap and a screw, fastened in centre thread of the shaft.
- The feather key must bear the complete hub length.




For further references see coupling manual

5 Electrical Connection

5.1 Pin Connection

Also see test certificate

12-pin	Analog Output	
Pin A	NC	
Pin B	NC	
Pin C	Signal	$\pm 5 \text{ V} / (\pm 10 \text{ V})$
Pin D	Signal GND	0 V
Pin E	Excitation GND	0 V
Pin F	Excitation +	12 ... 28 VDC
Pin G	Option Speed	TTL
Pin H	NC	
Pin J	NC	
Pin K	NC	
Pin L	NC	
Pin M	Housing	



View: socket on older side

5.2 Cable

Only use a shielded cable with preferably small capacity. We recommend measuring cables from our product range. They have been tested in combination with our sensors and meet the metrological requirements.


5.3 Shielding Connection

In combination with the sensor and the external electronics, the shield forms a Faraday Cage. By this, electro-magnetic disturbances do not have any influence on the measurement signal.

5.4 Running of Measuring Cables

Do not run measuring cables together with control or heavy-current cables. Always assure that a large distance is kept to engines, transformers and contactors, because their stray fields can lead to interferences of the measuring signals. If troubles occur through the measuring cable, we recommend to run the cable in a grounded steel conduit.

5.5 Speed Sensor (Option)



A hall sensor is located between the pulse wheel and the permanent magnet. If a tooth of the pulse wheel passes the energized hall sensor, the field intensity of the permanent magnet changes. By this, hall voltage occurs which is conditioned to a rectangular signal by the integrated evaluation electronics.

6 Measuring

6.1 Engaging

The warming-up period of the torque sensor is approx. 5 min. Afterwards the measurement can be started.



The warming-up period of the torque sensor is approx. 5 min.

6.2 Direction of Torque

Torque means clockwise or counter-clockwise torque if the torque acts clockwise when facing the shaft end. In this case a positive electrical signal is obtained at the output.

Torque sensors by burster can measure both, clockwise and counter-clockwise direction.

6.3 Static / Quasi-Static Torques

Static and/or quasi-static torque is a slowly changing torque.

The calibration of the sensors occurs statically on a calibration device.

The applied torque may accept any value up to the nominal torque.

6.4 Dynamic Torques

6.4.1 General

The static calibration procedure of torque sensors is also valid for dynamic applications.


Note: The frequency of torques must be smaller than the natural frequency of the mechanical measurement setup. The band width of alternating torque must be limited to 70 % of the nominal torque.

6.4.2 Natural Resonances

Estimate of the mechanical natural frequencies:

$$f_0 = \frac{1}{2 \cdot \pi} \cdot \sqrt{c \cdot \left(\frac{1}{J_1} + \frac{1}{J_2} \right)}$$

f_0 = Natural Frequency in Hz
 J_1, J_2 = Moment of Inertia in $\text{kg} \cdot \text{m}^2$
 c = Torsional Rigidity in Nm/rad



Further methods for the calculation of natural resonances are corresponding purchasable programs or books (e.g. Holzer-Procedure (Dubbel, Taschenbuch für den Maschinenbau, Springer Verlag)



Operation of the device in natural resonance can lead to permanent damages.

6.5 Speed Limits

The maximum speed indicated in the data sheet may not be exceeded in any operating state..

6.6 Disturbance Variables

By disturbances, measured value falsifications can occur by

- Vibrations,
- Temperature gradients,
- Temperature changes,
- Arising disturbance variables during operation, e.g. imbalance,
- Electrical disturbances,
- Magnetic disturbances,
- EMC (electromagnetic disturbances),

Therefore avoid these disturbance variables by decoupling of vibrations, covers, etc.

7 Maintenance

To a large extend, the torque sensor is maintenance-free

7.1 Maintenance Schedule

Action	Frequency	Date	Date	Date
Control of cables and connectors	1x p.a.			
Calibration	< 26 months			
Control of fixation (flanges, shafts)	1x p.a.			

7.2 Rotating Torque Sensors

To a large extend, this sensor type is maintenance free.

7.3 Trouble Shooting

This chart is used for searching for the most frequent errors and their elimination

Problem	Possible Cause	Trouble Shooting
No signal	No sensor excitation	<ul style="list-style-type: none"> • Outside of permissible range • Connect excitation • Cable defect • No mains supply
	Signal output connected wrong	<ul style="list-style-type: none"> • Connect output correctly • Evaluation electronics defect
Sensor does not react to torque	Shaft not clamped	<ul style="list-style-type: none"> • Clamp correctly
	No power supply	<ul style="list-style-type: none"> • Outside of permissible range • Connect supply • Cable defect • No mains supply
	Cable defect	<ul style="list-style-type: none"> • Repair cable
	Connector connected wrong	<ul style="list-style-type: none"> • Connect correctly
Signal has dropouts	Axial position rotor to stator outside of tolerance	<ul style="list-style-type: none"> • Align rotor
	Cable defect	<ul style="list-style-type: none"> • Repair cable
Zero point outside of tolerance	Cable defect	<ul style="list-style-type: none"> • Repair cable
	Shaft mounted distorted	<ul style="list-style-type: none"> • Mount correctly
	Distorted shaft string	<ul style="list-style-type: none"> • Release from distortion
	Strong lateral forces	<ul style="list-style-type: none"> • Reduce lateral forces
	Distorted flanges	<ul style="list-style-type: none"> • Check evenness of flange-surfaces
	Shaft overloaded	<ul style="list-style-type: none"> • Send to manufacturer
Wrong torque indication	Calibration not correct	<ul style="list-style-type: none"> • Re-calibrate
	Sensor defect	<ul style="list-style-type: none"> • Repair by manufacturer
	Torque shunt	<ul style="list-style-type: none"> • Eliminate shunt
Shaft drags	Shaft drags in the rotor	<ul style="list-style-type: none"> • Align shaft • Concentricity of the parts is not ensured
	Lateral forces too large	<ul style="list-style-type: none"> • Decrease lateral forces
Oscillations	Alignment of shaft not correct	<ul style="list-style-type: none"> • Align correctly
	Unbalance	<ul style="list-style-type: none"> • Balance the corresponding parts

8 Decommission

All sensors must be dismantled professionally. Do not strike sensor housings with tools. Do not apply bending moments on the sensor, e.g. through levers. The torque sensor must be supported to avoid falling down during the dismantling.

9 Transportation and Storage

The transportation of the sensors must occur in suitable packing.

For smaller sensors, stable cartons which are well padded are sufficient (e.g., air cushion film, epoxy crisps, paper shavings). The sensor should be tidily packed into film so that no packing material can reach into the sensor (ball bearings). Larger sensors should be packed in cases.

9.1 Transportation

Only release well packed sensors for transportation. The sensor should not be able to move back and forth in the packing. The sensors must be protected from moisture.

Only use suitable means of transportation.

9.2 Storage

The storage of the sensors must occur in dry, dust-free rooms, only.
Slightly lubricate shafts and flanges with oil before storing (rust).

10 Disposal

The torque sensors must be disposed according to the valid provisions of law.
For this, see our "General Terms and Conditions" www.burster.it

11 Calibration

At the time of delivery, torque sensors have been adjusted and tested with traceable calibrated measuring equipment at factory side. Optionally, a calibration of the sensors can be carried out.

11.1 Proprietary Calibration

Acquisition of measurement points and issuing of a calibration protocol Traceable calibrated measuring equipment is being used for the calibration. The sensor data are being checked during this calibration.

11.2 DKD-Calibration

The calibration of the sensor is carried out according to the guidelines of the DKD. The surveillance of the calibrating-laboratory takes place by the DKD. At this calibration, the uncertainty of measurement of the torque measuring instrument is determined. Further information can be obtained from burster Italia S.r.l.

11.3 Re-Calibration

The recalibration of the torque sensor should be carried out after 26 months at the latest.
Shorter intervals are appropriate:

- Overload of the sensor
- After repair
- After inappropriate handling
- Demand of high-quality standards
- Special traceability requirements

12 Data Sheet

See www.burster.it